



QUALITY WATER CARE

Spend more time relaxing
with a hands-free, total
water care solution

CLEARRAY® Water Management System

Getting Started

- 1 Fill hot tub with clean water to just above the highest jet
- 2 Using a test strip, test the water to determine levels of pH, Total Alkalinity and Calcium Hardness and adjust accordingly
- 3 Install Sundance® SunPurity™ mineral cartridge as directed
- 4 With the jets on, add the correct amount of chlorine sanitizer
- 5 Add the recommended dosage of SunPurity™ PLUS to your water
- 6 Run jets for 20-30 minutes with hot tub cover open and retest; be sure to monitor your hot tub for safety while cover is open

Sundance® Spas

Part No: 6890-346
10/17

Sundance® Spas

WATER CARE PLAN

AFTER EACH USE



- Add 1 teaspoon chlorine sanitizer and 1 cap-ful of shock. Run the jets for 20 minutes and open the cover.
- Add the recommended amount of shock after heavy use.

ONCE A WEEK



- Check the water using test strips to measure levels and adjust them as necessary.
- Add SunPurity™ PLUS to your water - it's best to do this step on the same day of the week, every week.

ONCE A MONTH



- Rinse and clean filters with garden hose or filter flosser.

EVERY 3 MONTHS



- Replace your Sundance® SunPurity™ mineral cartridge.
- If equipped, properly replace your Sundance® MicroClean® micro filter.
- If needed properly drain and refill your hot tub.
- Clean the cover and hot tub.

ONCE A YEAR



- Replace your CLEARARRAY® UV-C bulb.

ONCE EVERY 5 YEARS



- Replace your CLEARARRAY® PRO₃TECT™ Automatic Oxidizer.